EMINENT

MANUAL

EM65X0 - e-Domotica switch

WWW.EMINENT-ONLINE.COM

EM65X0 - e-Domotica switch

Warnings and points of attention

Due to laws, directives and regulations set out by the European Parliament, this device could be subject to limitations concerning its use in certain European member states. In certain European member states the use of this product could be prohibited. More information regarding this warning can be found in the Declaration of Conformity on the last page of this document!

Table of contents

1.0 Introduction 2
1.1 Functions and features 2
1.2 Packing contents 3
2.0 Using the switch 3
2.1 Connecting to a wall outlet....3
2.2 Assigning the switch to the Eminent e-Centre....3
2.3 Adding the switch to the already installed e-Centre....3
2.4 Removing the switch....4
3.0 Frequently asked questions....4
4.0 Service and support....5

1.0 Introduction

Congratulations with the purchase of this high-quality Eminent product! This product has undergone extensive testing by Eminent's technical experts. Should you experience any problems with this product, you are covered by a five-year Eminent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.eminent-online.com and receive product updates!

1.1 Functions and features

The wireless EM65X0 e-Domotica switch, allows you to turn on and turn off your illumination and other electrical devices by using a remote control. In combination with the Eminent e-Centre, you can save a lot on your electricity account and reduce the amount of stand-by consumption. You will not only save money, but you will also protect the environment by using the EM65X0. The switch can be connected to any free wall outlet, and therefore can be used throughout your entire house. The switch can also act as a repeater, by picking up the wireless signal of other e-Domotica devices and broadcast this signal forward. This way, you can make sure your entire house is provided with the comfort the EM65X0 delivers!

1.2 Packing contents

The following parts need to be present:

- EM65X0 wireless switch
- User manual

2.0 Using the switch

Only a few short and simple steps are necessary in order to connect and assign the EM65X0 to the e-Centre and let the functioning of the EM65X0 begin. Use the following procedure to connect the switch.

2.1 Connecting to a wall outlet

1. Take the switch out of the packaging.
2. Insert the switch into a wall outlet.
3. Insert the plug of the device you want to switch (For example: a lamp) into the socket of the EM65X0.
4. If the device has its own on/off switch, you have to set this switch to the 'ON' position.
5. Test whether the device works by pressing the button on the switch. The LED on the switch will be lit. The connected device will also be turned on.

2.2 Assigning the switch to the Eminent e-Centre

There are two situations possible when assigning the switch to the Eminent e-Centre.

1. You assign the switch to the Eminent e-Centre during the installation process of the e-Centre itself. The installation wizard of the e-Centre will move along the 9 steps during the installation process of the e-Centre itself, meaning you can add all your e-Domotica devices through the e-Centre's own website "http://e-Centre". For this installation you have to follow the steps shown on screen.
2. You can add your switch to the already installed e-Centre. This is described in chapter '3.3. Adding the switch to the already installed e-Centre'.

2.3 Adding the switch to the already installed e-Centre

1. Insert the new switch into a wall outlet near the e-Centre (5 meters maximum).

When assigning the switch, a shorter distance is required compared to repeating, or being in service.

2. Make sure your computer is completely started.
3. Open your computer's web browser.

4. Fill in “http://e-Centre” in the address bar of your web browser and press the ‘Enter’ key on your keyboard.
5. The openings screen of the Eminent e-Centre will be shown.
6. Click the ‘Add’ button. The e-Centre will start to search for new e-Domotica devices.
7. Press the button on your new switch.
8. A message will appear: ‘Product found’.

If the device is not found, press the ‘Reset’ button in the e-Centre’s webpage and then click the button on your switch. After this procedure you can add the new device correctly.

9. Give the connected and found device a name and choose a location and click ‘Save’.
10. The switch has now been added to the e-Centre. The e-Centre will now be able to control the switch.

If the switch is placed at a distance of more than 25 meters, you can now insert the switch in a wall outlet at the desired location. Choose ‘e-Domotica devices’ in the e-Centre’s webpage, then choose the ‘Optimize’ option. By doing so, your wireless network will be optimized for maximum range.

2.4 Removing the switch

1. Make sure your computer is completely started.
2. Open you computer’s web browser.
3. Fill in “http://e-Centre” in the address bar of your web browser and press the ‘Enter’ key on your keyboard.
4. The openings screen of the Eminent e-Centre will be shown.
5. Click the ‘Remove’ button.
6. Press the button on your switch.
7. The device has now been deleted.

3.0 Frequently asked questions

Q: What is the maximum wireless range of my e-Domotica devices?

A: Thanks to the network’s repeating option (amplifiers), the wireless range of the e-Domotica devices is virtually unlimited. Both the EM65X0 switch and the EM65X1 dimmer act as a repeater. Without repeating, the maximum wireless range indoor is approximately 25 meters. You can optimize the wireless range by adding an extra EM65X0 switch or EM65X1 dimmer, and then use the ‘Optimize’ function in the e-Centre’s webpage.

Q: What is de maximum save amount of electrical power the switch can handle?

A: The switch can handle devices with the following specifications: A maximum load of 2990 Watts, lighting bulp with a maximum load of 1500 Watts, energy saving lamps and fluorescent lamps with a maximum load of 15x40 Watts.

Q: The manual mentions 'standby consumption'. What exactly does this mean?

A: Devices are regularly set to the 'Standby' mode the moment these devices are not in use. This 'Standby' mode always consumes electrical power. Some older devices, without a 'Standby' mode, do even consume electrical power when switched off but connected to a wall outlet.

4.0 Service and support

This users manual has been carefully written by Eminent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.eminent-online.com/support. You can also contact us by phone. Below you will find a list with phone numbers for each supported country.

Country	**Phone number**	**Rate per minute***
Belgium (Dutch)	070 277 286	€0.30
Belgium (French)	070 277 286	€0.30
Denmark	+45 69918565	Local Costs
Finland	+35 8942415826	Local Costs
Germany	1805 982 234	€0.14
Italy	+39 0240042016	Local Costs
Norway	+47 21075033	Local Costs
Spain	807 080 042	€0.41
Sweden	+46 840 309985	Local Costs
The Netherlands	0900-3646368	€0.45
UK	905 871 0013	Local Costs

* Rates mentioned in this table do not include cell phone charges.

Warranty conditions

The five-year Eminent warranty applies to all Eminent products unless mentioned otherwise before or during the moment of purchase. When having bought a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's first owner.
The Eminent warranty applies to all Eminent products and parts inextricably connected to and/or mounted on the main product. Power supply adapters, batteries, antennas and all other products not integrated in or directly connected to the main product and/or products of which, without reasonable doubt, can be assumed that wear and tear show a different pattern than the main product are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when subjected to incorrect/improper use, external influences and/or when opened by parties other than Eminent.

Declaration of Conformity

To ensure your safety and compliance of the product with the directives and laws created by the European Commission you can obtain a copy of the Declaration of Conformity concerning your product by sending an e-mail message to: info@eminent-online.com. You can also send a letter to:

Eminent Computer Supplies
P.O. Box 276
6160 AG Geleen
The Netherlands

Clearly state 'Declaration of Conformity' and the article code of the product of which you would like to obtain a copy of the Declaration of Conformity.

EMINENT

WWW.EMINENT-ONLINE.COM

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.
The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.

Eminent is a member of the Intronics Group

CE